

# AP242 - Flying Circus Jenny - Jenny Cirque Volant - Flying Circus Jenny

1. Place fuselage (plane body) through wings as shown in the illustration.
2. Position the bracket for the pontoons over the two holes.
3. Attach fuselage, and pontoons to wings with the 2 enclosed screws.
4. Attach propeller to airplane with the propeller axle by sliding the axle through the hole in the propeller then into the nose of the fuselage.

1. Placez le fuselage (le corps de l'avion) entre les ailes, conformément au dessin ci-contre.
2. Placez le support des flotteurs sur les deux trous.
3. Fixer le fuselage et les flotteurs aux ailes avec les deux vis fournies.
4. Fixez l'hélice à l'avion avec l'axe de l'hélice, en glissant celui-ci à travers le trou dans l'hélice puis dans le nez du fuselage.

1. Platzieren Sie den Flugzeugrumpf wie auf der Abbildung dargestellt zwischen den Flügeln.
2. Platzieren Sie die Klammer für die beiden Schwimmer über den beiden Löchern.
3. Befestigen Sie den Rumpf und die beiden Schwimmer mit den beiden mitgelieferten Schrauben an den Flügeln. Befestigen Sie den Propeller am Flugzeug, indem Sie die Propellerachse erst durch das Loch im Propeller stecken und dann in die Nase des Rumpfes.




Illustration shows the bottom side of the plane.  
Le dessin montre le dessous de l'avion.  
Die Abbildung zeigt die Unterseite des Flugzeuges.

The Netherlands  
AM NL  
Ambachtsweg 37  
NL-3899 AM  
Zeewolde

United States  
AM USA  
888 Garfield  
P.O. Box 21710  
Eugene, OR 97402

